

Mini Dome Network Camera **Quick Setup Guide**

Fully understand this document before using this device, and strictly observe rules in this document when using this device. If you install this device in public places, provide the tip "You have entered the area of electronic surveillance" in an eye-catching place. Failure to correctly use electrical products may cause fire and severe injuries.

MARNING avoided, may cause minor or moderate injur		It alerts you to moderate dangers which, if not avoided, may cause minor or moderate injuries.
		It alerts you to risks. Neglect of these risks may cause device damage, data loss, device performance deterioration, or unpredictable results.
NOTE It provides additional information.		It provides additional information.

- · Strictly observe installation requirements when installing the device. The manufacturer shall not be held responsible for device damage caused by users' non-conformance to these requirements
- Strictly conform to local electrical safety standards and use power adapters that are marked with the LPS standard when installing and using this device. Otherwise, this device may be damaged.
- Use accessories delivered with this device. The voltage must meet input voltage requirements for this device.
- · If this device is installed in places with unsteady voltage, ground this device to discharge high energy such as electrical surges in order to prevent the power supply from burning out.
- · When this device is in use, ensure that no water or any liquid flows into the device. If water or liquid unexpectedly flows into the device, immediately power off the device and disconnect all cables (such as power cables and network cables) from this device

· Do not focus strong light (such as lighted bulbs or sunlight) on

this device. Otherwise, the service life of the image sensor may be shortened.

· If this device is installed in places where thunder and lightning frequently occur, ground the device nearby to discharge high energy such as thunder strikes in order to prevent device damage.

2 CAUTION

- Avoid heavy loads, intensive shakes, and soaking to prevent damages during transportation and storage. The warranty does not cover any device damage that is caused during secondary packaging and transportation after the original packaging is taken apart.
- Protect this device from fall-down and intensive strikes, keep the device away from magnetic field interference, and do not install the device in places with shaking surfaces or under shocks.
- · Clean the device with a soft dry cloth. For stubborn dirt, dip the cloth into slight neutral cleanser, gently wipe the dirt with the cloth, and then dry the device.
- · Do not jam the ventilation opening. Follow the installation instructions provided in this document when installing the device. Keep the device away from heat sources such as radiators.
- electric heaters, or other heat equipment. · Keep the device away from moist, dusty, extremely hot or cold
- places, or places with strong electric radiation. If the device is installed outdoors, take insect- and moisture-
- proof measures to avoid circuit board corrosion that can affect monitoring. • Remove the power plug if the device is idle for a long time.
- · Before unpacking, check whether the fragile sticker is damaged. If the fragile sticker is damaged, contact customer services or sales personnel. The manufacturer shall not be held responsible for any artificial damage of the fragile sticker.

Open Package Examination

Open the package, check the appearance of product for no obvious damage, and confirm the item list for table 1-1 is consistent

Table 1-1 Packing list

Component	Quantity	Remark
Mini Dome Network Camera	1	
Quick Setup Guide	1	
Installation location sticker	1	
T15 screwdriver	1	
Stainless self-tapping screw PA4.0×30mm	2	
Swell plastic button φ5.6×29mm	2	
Video patch cord	1	
Network access port protective cover	1	
Waterproof rubber seal	1	

~	
2	Device Structure

2.1 Device Ports

NOTE

Different device may have different ports and multi-head cable, please refer to the actual product.

orts




Table 2-1 Hardware ports description

Port Name	Description	Remark
BNC Video	Sends analog video signals. You can connect the camera to a TV monitor through this port to view analog videos.	
Power indicator	When the camera is operating, the indicator flashes.	
NIC indicator	When there is a network activity, the indicator flashes.	
SD card indicator	Indicate the card status, the status is described as follows: • Off: No card is inserted • On: A SD card is inserted.	
SD card slot	Install a SD card. Before install a SD card, verify the card not in write protection state. Before remove the SD card. Verify the card not in write protection state. Otherwise, the data may be lost, or the SD card may be damaged.	
MIC socket	connect a inner MIC.	Applied for camera with inner MIC

Port Name	Description	Remark
	Restores the camera to the factory settings by pressing and holding this button for more than five seconds.	







Table 2-2 Multi-head cable description


ID	Core	Description	Remark
1	Network access port	Connects to a standard Ethernet cable.	
2	Audio input port	Receives an analog audio signal from devices such as a sound pickup device.	Applied for camera
3	Audio output port	Connects to an external audio device such as a speaker.	with audio function
4	Power supply (DC 12V)	Connects to a 12V(-15%-+10%) direct current (DC) power supply.	
5	Gray core	Alarm output terminal A(normal open)	Applied
	Purple core		for
	Yellow core	Alarm input positive terminal	alarm function
	Orange core	Alarm input ground terminal	

2.2 Camera Dimensions

NOTE

Different device may have different dimensions, please refer to the actual product.





Device Installation

To avoid the impact of humidity, after installing the device, power on the device for at least half an hour before sealing the cover.

The Mini Dome Network Camera can be installed in ceiling mounting or side wall mounting mode. In general, it is used in an indoor or building environment, but can also be used in an outdoor environment.

Installation Steps:

Step 1 Unfasten the two screws on the cover of the mini dome by using the T15 screwdriver in the accessory package and open the cover upward, as shown in figure 3-1.

	Dilli Hole
nt	
are delivered ccessories after neld responsible	BNC Video — Power indicator —

	Figure 2-1 Hardware po
ot	Drill hole

- · All complete products sold by the manufacturer and along with nameplates, quick setup guide and acc strict inspection. The manufacturer shall not be here for counterfeit products.
- · The manufacturer will update this manual according to product function enhancement or changes and regularly update the software and hardware described in this manual. Update information will be added to new versions of this manual without
- prior notice. This manual may contain misprints, technology information that is not accurate enough, or product function and operation description that is slightly inconsistent with the actual product,
- the final interpretation of company is as a standard. This manual is only for reference and does not ensure that the
- information is totally consistent with the actual product. For consistency, see the actual product.


NOTE

For more information, please refer website.

NOTE


Open the cover gently and pull out the MIC line from the MIC socket, be careful not to snap the MIC line.

Figure 3-1 Opening the cover



- Step 2 Stick the Installation location sticker on the required installation position, Drill two holes based on the "DRILL HOLES"marks on the sticker. Drive the swell plastic buttons into the holes. Step 3 Connect the multi-head cable.
- Step 4 Align the two installation holes at the bottom of the camera with the two Swell plastic buttons, take out two black selftapping screws in the accessory package, and install the camera on the mounting surface as shown in figure 3-2.

Figure 3-2 Installing the camera




Step 5 Unfasten the screws on both sides of the lens until you can turn the lens dome manually, adjust the angle of the lens dome until a satisfactory effect is achieved, and then fasten the screws again as shown in figure 3-3.

III NOTE


In this step, you can perform operations such as inserting or removing the SD card, resetting a function, and adjusting a video.

Figure 3-3 Adjusting the camera direction



Step 5 Connect the MIC plug to the MIC socket(ignore the operation if no MIC function) and install the cover by using the T15 screwdriver as shown in figure 3-4.

Figure 3-4 Installing the cover



4 Quick Configuration(e.g IE)

4.1 Login

Step 1 Open the Internet Explorer, enter the IP address of IP camera (default value: 192.168.0.120 in the address box, and press Enter. The login page is displayed. as shown in figure 4-1. Step 2 Input the user name and password.

NOTE

The default user name is admin. The default password is admin. Change the password when you log in the system for first time to ensure system security. You can change the system display language on the login page.

Figure 4-1 Login

Choose Configuration > Device > Local Network, the Local

Enter the IP address in the IP Address box and click Apply as shown

Figure 4-2 Local Network

To ensure the real-time video can be played properly, you must

Step 1 the Internet Explorer. Choose Tools > Internet options >

Step 2 In the Internet Explorer, choose Tool > Internet Options >

plug-ins to Enable, as shown in figure 4-4.

Add, as shown in figure 4-3.

perform the following operation when you log in the web for the first time:

Security > Customer level, and set Download unsigned ActiveX control and initialize and script ActiveX controls not marked as safe for scripting under ActiveX controls and

Security > Trusted sites > Sites, in the display dialog box, click

IPV4

255.255.255.0

192.168.241.1

Refresh Apply

OFF

After the success of the IP address setting, please use the new IP

Step3 Click Login, the main page is displayed

4.2 Modify IP address

in figure 4-2

Network page is displayed.

Local Network

IP Protocol

Subnet Mask

4.3 Browsing Video

Default Gateway

Preferred DNS Server

Alternate DNS Server MTU(800-1500)

DHCP IP Address

address to log in the Web interface.



General Security Privacy Content	control in the state in the				
Select a zone to view or change securit internet Local intranet Truste	/ 🛇				
Trusted sites This zone contains websites the	nat you				
 trust not to damage your com your files. You have websites in this zon 		Trustee		on websites from this zo	ne. Al websites
V trust not to damage your com your files. You have websites in this zon Security level for this zone		Trustee			ne. All websites
 trust not to damage your com your files. You have websites in this zone Security level for this zone Allowed levels for this zone: All 			You can add and remo-		ine. All websites
trust not to damage your com your files. You have websites in this zon Security level for this zone Allowed levels for this zone: All Low Minimal safeguards an	e. d warning prompts are provide	d Age	You can add and remon this zone will use the zone is website to the zone:		
trust not to damage your com your files. You have websites in this zon Security level for this zone Allowed levels for this zone: All Low Minimal safeguards an	e. d warning prompts are provide saded and run without prompt	d Age	You can add and remo- this zone will use the zo		ne. All websites
trust not to damage your com your files. You have websites in this zon Security level for this zone: All Allowed levels for this zone: All - Low - Minimal safeguards an - Most content is down - All active content can	e. d warning prompts are provide saded and run without prompt	d Age	You can add and remo- this zone will use the zone is website to the zone: //192.168.0.120		
trust not to damage your com your files. You have websites in this zon Security level for this zone: All Allowed levels for this zone: All - Low - Minimal safeguards an - Most content is down - All active content can	e. d warning prompts are provide saded and run without prompt	d Add th https: <u>Wiebsi</u>	You can add and remot this zone will use the zone is website to the zone: //192.168.0.120 es: icon.com		
Instanto to demage your com your files. You have websites in this zone Security level for this zone Alowed levels for this zone: Al -	e. d warning prompts are provide oaded and run without prompt run hat you absolutely trust	d Add th https://websile. Websile. *.http: *.http: *.http://websile. *.http://websile. *.http://websile.	You can add and remo this zone will use the zo is website to the zone: //192.168.0.120 es: ficon.com kon.com wel.com		êdd
Instanto to demage your com your files. You have websites in this zone Security level for this zone Alowed levels for this zone: Al -	e. d warning prompts are provide saded and run without prompt	d Add th Mebsi "https: "http: " http: "http: "http: "http: "http: "http: "http:	You can add and remo- this zone will use the zone: is website to the zone: //192.168.0.120 es: licon.com licon.com swel.com swel.com		êdd
Very trust not to demage your com your fire. You have vertestes in this zon Security levels for this zone Allowed levels for this zone Allowed levels for this zone 	e. d warning prompts are provide oaded and run without prompt run hat you absolutely trust	d Add the Property of the Prop	You can add and remo this zone will use the zo is website to the zone: //192.168.0.120 es: ficon.com kon.com wel.com		êdd

Figure 4-3 Adding a trusted site

Figure 4-4 Configuring ActiveX control and plug-in

Security investor forces on a result of the security and the security investor in a security investor in the security inv	Internet Options	<u>? x</u>
The same tarmer change used yr atterns.	General Security Privacy Content Connections Programs Adv	vanced
Control of the state of th	Select a zone to view or change security settings,	Security Settings - Internet Zone
bernet brance	Internet Local intranet Trusted sites Restricted	Activeti controls and plagens Adov previously unused Activetic controls to run without prom
encycl those Market hunder and encycle those Market hunder hunder and encycle those Market hunder hunder and encycle those Market hunder hunder hunder and encycle those Market hunder hu	Internet	C trable Alow Scriptlets
Security level for the same Contern C	except those listed in trusted and	Enable
Cardem Cardon Marine State States News. - To use the recommended settings, ddb. Dafaak level. Cardon News	-Security level for this zone	Automatic prompting for ActiveX controls Disable
© Erable Quatom level	Custom settings. - To change the settings, click Custom level,	Binary and script behaviors Administrator approved
Gustom level Default level Reset custom settings	 to use the recommended security, ducided autoretic 	Enable Display unless and animation on a watersame that does not use
Death discussion default hand a second	Sustom level Default level	
	Reset all zones to default level	
	OK Cancel A	coty OK Cancel

Step 3 Download and install the player control as prompted.

D NOTE

If the repair tips displayed when installing the control, please ignore the prompt, and continue the installation, the login page is displayed when the control is loaded.

To browse a real-time video, click Live Video. The Live Video page is displayed, as shown in figure 4-5.

Figure 4-5 Live Video



4.4 Two-way audio

NOTE

Partial camera do not support two-way audio, this section do not apply.

4.4.1 Camera - PC

Connection

Step 1 Connect microphone to audio input interface of camera. Step 2 Connect speaker to the PC audio output interface. Step 3 Log in camera Web, click to turn on two-way audio.

4.4.2 PC ____ Camera

Step1 Connect microphone to PC audio input interface. Step2 Connect speaker to camera audio out interface. Step3 Log in camera Web, click to turn on two-way audio.

4.5 Alarm Configuration

NOTE

Partial camera do not support alarm, this section do not apply.

Alarm input and Alarm output connection:

- Step1 Connect alarm input device to Alarm IN0 and Alarm COM0 of multi-head cable.
- Step2 Connect alarm output device to Alarm OUT1 and Alarm COM1 of multi-head cable, alarm output interface can connect to normal open device only.
- Step3 Log in Web, Choose Configuration>Alarm>I/O Alarm, set the parameters as shown in figure 4-6.
- Step4 Choose Configuration>Alarm>I/O Alarm Linkage, enable the I/O Alarm and set the parameters of Schedule Setting.

Figure 4-6 Alarm

I/O Alarm	
Alarm input	1
Name	1
Valid Voltage Level	High -
	× .
Alarm output	1
Name	
Valid Signal	Close -
Alarm Output Mode	Switch Mode -
Alarm Time(ms)(0:Continuous)	0
	✓
Manual Control	Start Stop
	Refresh